

INSTALLATION CHECKLIST

For all installed villa systems, the following steps shall be carried out.

01. Order via the webshop

Place order in the webshop
(include necessary
equipment)

02. Correct electricity trading company/BRP

Inform customer of conditions with regard to electricity trading company/BRP. See the list of compatible electricity trading companies via the button below.

Compatible electricity trading companies

03. Install

Install according to CheckWatt's instructions. You can find the manuals in the Installer Portal via
<https://kp.checkwatt.se/installer/documents/>

The manuals can also be found at
<https://checkwatt.se/installation>

Installatörsportalen

04. Register

Scan the QR code and fill in the customer and facility details. Alternatively go to
<http://register.checkwatt.se>

Register

05. Check

Check that the CM10 has internet access. Instructions can be found in the installation manual.

After steps 01-05 are completed, the system is tested by CheckWatt within 3-5 working days. Provided that everything works as it should, the system is put into operation.

06. Monitor

Site Status gives you an overview of your systems. As an installer, you are responsible for the operation of the systems you have installed, which means that the systems need to be monitored to ensure that everything is working properly. In case of problems that cannot be solved with troubleshooting guides, contact CheckWatt.

Site Status